


Monarch® 1103®-1110® Labelers




Operating Instructions


TC10000I Rev. DG 2/09 ©2007 Avery Dennison Corp. All rights reserved. LOADING LABELS & SETTING PRINT BANDS

LOADING LABELS

If labeler has no label guide: Snap label roll between hubs. Tear off and discard first twelve labels and backing paper.



Continue feeding label strip until about twelve labels come out here. Release operating lever.




If labeler has label guide: Snap

label roll between hubs. Tear off


and discard first twelve labels and

a. Feed label strip up under plate until two labels come out here.




b. Squeeze operating lever halfway and rewind label roll until loop is


Squeeze and hold operating lever half way, and feed label strip under brake wheels.




Grasp label strip and pull briskly toward operating lever.



labels.




Completely squeeze operating lever, exposing feedwheel. Insert backing paper into slot. When paper bows up, maintain finger pressure and release operating lever.



Squeeze operating lever several times until backing paper exits labeler. If backing paper does not become taut and exit at rear, remove backing paper from slot and repeat steps 6 and 7.

SETTING PRINT BANDS

Pull knob until indicators point to desired band.



Turn knob until indicators point to desired character or blank.




Make sure the character you select is not a print character (UPSIDE DOWN). You should be able to read the character correctly through the band window.


3 Set all bands and push knob in all the way.

INKING

Turn latch to release ink roll door and carefully pull it completely out of labeler.




Pold a piece of scrap backing paper.




Insert folded backing paper between ink roll and carrier. Pull to snap old ink roll free.



Cut off end of new ink roll pouch. Using pouch to protect fingers, slide carrier into pouch and snap new ink roll into carrier (one side at a time).



5 Insert ink roll into ink door opening. Tilt ink door and press in . . .



Latch ink roll door securely.